

# OPERATION RSBJ1650



Prepared the cable, cut and remove cable sheath.



Installation the clip of shield



Tight wraps the edge of cable with adhesive tape.



Install the shield bracket



Wraparound the mesh



Tight wraps the edge of mesh with adhesive tape



Remove the tape of the edge of PE package.



Wraparound joint with PE package, tight wrap the edge of it.



Fill sealing resin to top of mesh



Pucker the PE package from top to the end.



Tight wraps with PE package



Center the liner over splice



Place a mark on the cable just outside of the edge sleeve



Place another mark inside of the first one 10mm



Make the aluminum foil conform to cable



Abrade the cable sheath circumference on the cleaned area with abrasive strip.



Tightly wrap one half-lapped over canister with adhesive tape



Install sleeve



Continue heating evenly around sleeve from center to end until entire sleeve is recovered



complete the installation